



## Care and Maintenance

### **CLEANING:**

To keep your AZEK Deck looking its best:

- Wash deck periodically to remove grease, dirt and debris.
- AZEK Deck can be cleaned using liquid soap such as dish, car wash or specially formulated all purpose deck cleaners. Rinsed with a garden hose.
- For rust stains, use a household cleaner with phosphoric acid as the active ingredient (generally toilet bowl cleaners work well). Rinse with garden hose.
- Avoid using cleaners containing abrasives which can dull the surface of the deck board.
- Avoid the use of rubber-backed mats.

### **ICE REMOVAL:**

For Ice Removal:

- Rock Salt or calcium chloride can be used without damage to the deck surface
- Both products may leave a white residue, which can be cleaned using the cleaning guidelines above.

**End**