



TrapEase

COMPOSITE WOOD DECK SCREW

NO MORE MUSHROOMS!

Specially designed to eliminate the “mushrooming” effect caused by standard deck screws in composite deck materials.

The design features of this FastenMaster product include:

- Oversized top thread traps most loose composite material during installation
- Concave underside of the head traps any additional loose material, pushing it back into the hole
- Guaranteed corrosive resistant coating greatly outperforms standard galvanized coating in salt air and acid rain environments
- Sharp piercing point cuts through the composite material in the first rotation
- Deep #2 square-drive provides the best bit engagement, reducing cam out



NO MORE MUSHROOMS!



STANDARD DECK SCREW



TRAPEASE



For more information or free samples, call FastenMaster at 800•518•3569.

MG
Fasten Master™
Mastering the Tough Fastening Jobs!
TrapEase
COMPOSITE WOOD DECK SCREW

INSTALLATION PROCEDURE

Use a 0-1800 RPM variable speed corded or 18V cordless drill. Use the #2 square driver bits provided. Install fastener perpendicular to deck, increasing drill speed as the screw threads into the deck. Drive the screw flush. Do not overdrive. If cam out occurs, remove and replace screw.

Refer to the composite wood manufacturer's technical literature for fastening pattern and requirements. Commonly accepted fastening practices include:


- Installing two screws at every joist.
- Predrilling pilot holes when fastening the ends of boards to avoid splitting (within 1 1/2" of end of board, based on manufacturer's specs).
- Installing screws no closer than 3/4" from the edge of the board.

Note: When building with Correct Deck, quickly "dimple" or "divot" the top surface of the material with a 1/4" bit before installing the TrapEase. This divot should be 1/16" to 1/8" deep. After "dimpling" the surface, drive the fasteners flush. Do not overdrive the fastener as spin out is likely to occur.

COLOR MATCH NOTE

The FastenMaster TrapEase is available in various colors. Refer to the composite lumber manufacturer's technical data to determine what color their lumber will fade to. This may be different from its color at time of purchase. Choose a fastener to match this faded color.

NO MORE MUSHROOMS!



Part Number	Color Code	Screw Length	Quantity per Box	Square Feet of Deck Surface*
FMTR9212-75GY	Gray	2 1/2"	75	20
FMTR9212-350GY	Gray	2 1/2"	350	100
FMTR9212-1750GY	Gray	2 1/2"	1750	500
FMTR9212-75BR	Brown	2 1/2"	75	20
FMTR9212-350BR	Brown	2 1/2"	350	100
FMTR9212-1750BR	Brown	2 1/2"	1750	500
FMTR9212-75DR	Dark Redwood	2 1/2"	75	20
FMTR9212-350DR	Dark Redwood	2 1/2"	350	100
FMTR9212-1750DR	Dark Redwood	2 1/2"	1750	500
FMTR9212-75LR	Light Redwood	2 1/2"	75	20
FMTR9212-350LR	Light Redwood	2 1/2"	350	100
FMTR9212-1750LR	Light Redwood	2 1/2"	1750	500

*Based on a fastening pattern of 2 screws per joist, spaced every 16", into standard 6" wide decking

BP03006-75W-AML